

Cleaning

- Open the drain plug (1/14) or the drain valve. Wash out the deposits.
- If there are any encrustations, remove the top and bottom flange (dependent on the model).
- Carefully remove the float.
- Clean the BNA mechanically.
- Check all flanges, discharge tubes and vent plugs for firm seat and tightness at regular intervals.
- Check the sealing carefully. Replace graphite gaskets immediately when damaged.

 IMPORTANT
The orderer must ensure that the inspection intervals required for his plant are observed.
Indicators provided with a heating jacket covering the inner weld seams must be subjected to a pressure chamber leak test at intervals to be specified by the operator. This is to recognize corrosion-conditioned leaks of a weld seam exposed to the process medium, and to prevent that process medium from entering the heating circuit.

8 Technical Data

	BNA 21/22		BNA 31/36		BNA 41/42		BNA 45/46	
Tube and flange material	1.4571							
Float material	NBR foamed*, 1.4571 or titanium		1.4571 or titanium		1.4571 or titanium			
Media temperature range	Max. -40°C...+ 150°C (ex area according to ATEX -20°C- +60°C)				Max. -40°C...+ 320°C (ex area according to ATEX -20°C- +60°C)			
Process connection	G1/2"	on the side	G1/2"	on the side	G1/2"	on the side	G1/2"	on the side
Maximum permissible pressure	PN 16				PN 40			
Refer to data sheets for further technical data, dimensions and options								

* not suitable for ATEX

Nameplate

For ex equipment (example)

<p>MADE IN GERMANY</p> <p> II 1/2 G c II C TA = -20°C bis +60°C TUV 08 ATEX 554726x</p> <p> 0044</p> <p>Die Betriebsanleitung und die Ex-Bescheinigung sind zu beachten</p> <p>switches must be used in accordance with the standards and our instruction</p>	<p>Barksdale GmbH Dorn-Assenheimer Str. 27 D-61203 Reichelsheim</p> <p>Art.Nr. / Part No. Barksdale CONTROL PRODUCTS</p> <p>Type / type _____</p> <p>DWG No. / DWG No. _____</p> <p>Serialnummer / Serial No. _____</p> <p>Anschlüsse / Connection _____ Nenndruck / nom. Pressure _____</p> <p>Max. Medium Temp. / Max. Fluid Temp. _____ Min. Drücke / Min. Density _____</p>
---	--

9 EC type examination certificate

Ex equipment: observe the EC type examination certificate. See appendix.

Operating Instructions
Bypass Level Indicator



1	Intended Applications	2
2	Safety Instructions.....	3
3	Standards	4
4	Warranty/Guaranty.....	4
5	Principle of Operation	4
6	Installation/Commissioning	5
7	Maintenance	7
8	Technical Data.....	8
9	EC type examination certificate.....	8

Barksdale GmbH
Dorn-Assenheimer Straße 27
D-61203 Reichelsheim

Phone: +49 (6035) 949-0
Fax: +49 (6035) 949-111 und 949-113
eMail: info@barksdale.de
Internet: www.barksdale.de

Art. no. 923-0663
Index D, 17.02.2009
Specifications are subject
to changes without notice!
Refer to data sheet for further
technical data.



1 Intended Applications

The Bypass Level Indicator (BNA) serves exclusively for indicating a level corresponding to that of the connected tank. Control devices such as solenoid switches or remote indicators can be additionally installed by Barksdale.

The manufacturer assumes the responsibility for correct execution of the equipment according to the orderer's instructions. The orderer assumes the responsibility for the correct installation and use of the equipment subject to the applicable national regulations.

DANGER

Read the operating instructions and the safety instructions carefully before using the Bypass Level Indicator (BNA). Nonobservance may cause injuries to health or material damage. Barksdale GmbH cannot be held liable for any damage resulting from incorrect use.

The Bypass Level Indicators (BNA) must not be used in situations in which lives depend on proper functioning of the equipment.

The Bypass Level Indicator may exclusively be used in the specified fields of application and with the permissible data (see nameplate). The temperature ranges must be within the permissible limits. The stated pressures and electrical load values must not be exceeded.

The orderer ensures that exothermic reactions or spontaneous gas-phase formation of the medium are impossible.

Observe also the applicable national safety instructions for assembly, commissioning and operation of the Bypass Level Indicator.

CAUTION

If the medium is water and there is a risk of icing the water must be discharged from the Bypass Level Indicator (BNA) or heating must be provided to prevent damage to the float or the indicator tube.

The maximum speed of the float caused by level changes must not exceed 1 m/s. If necessary a suitable screen must be installed by the orderer in the connection to the tank.

IMPORTANT

Unless agreed otherwise the Bypass Level Indicator (BNA) is designed for static operating conditions. If any vibrations are to be expected, e.g. by pumps, compressors etc., the orderer must provide for adequate vibration absorption.

The classification of ex devices is stated on the EC type examination certificate. The designation  II 1/2 G permits use in potentially explosive gas atmosphere outside the equipment in zone 1; inside the equipment zone 0 is permitted.

CAUTION

 In ex areas the orderer must not use any plastic bypass level indicators (BNA) because of the risk of electrostatic charging.

If the Bypass Level Indicator (BNA) is determined for use in potentially explosive atmosphere, it must be checked whether the damper has been installed in the bottom flange. The BNA must be suitable for the intended according to its nameplate.

In case of use in zone 0, the maximum process temperatures according to the temperature class and the permissible pressure range in the tank of 0.8 to 1.1 bar in case of potentially explosive temperature must be observed. If the Bypass Level Indicator (BNA) is operated in potentially explosive atmosphere outside the permissible pressure and temperature ranges in the tank mentioned above, the type examination certificate serves only as a guideline.

Additional examinations for the specific operating conditions are recommended.

2 Safety Instructions

The safety instructions are intended to protect the user from dangerous situations and/or material damage.

In the operating instructions the seriousness of the potential risk is designated by the following signal words:

DANGER

Refers to imminent danger to men.

Nonobservance may result in fatal injuries.

WARNING

Refers to a recognizable danger.

Nonobservance may result in fatal injuries, and destroy the equipment or plant parts.

CAUTION

Refers to a danger.

Nonobservance may result in minor injury and damage to the Bypass Level Indicator (BNA) and/or the plant.

IMPORTANT

Refers to important information essential to the user.

Disposal

The Bypass Level Indicator must be disposed of correctly in accordance with the local regulations for electric/electronic equipment.

The Bypass Level Indicator must not be disposed of with the household garbage!

3 Standards

The standards applied during development, manufacture and configuration are listed in the CE conformity and manufacturer's declaration.

4 Warranty/Guaranty

Warranty

Our scope of delivery and services is governed by the legal warranties and warranty periods.

Terms of guaranty

We guaranty for function and material of the Bypass Level Indicator under normal operating and maintenance conditions in accordance with the statutory provisions.

Loss of guaranty

The agreed guaranty period will expire in case of:

- incorrect use
- modifications to the equipment
- incorrect installation
- incorrect handling or operation contrary to the provisions of these operating instructions

No liability is assumed for any damage resulting therefrom, or any consequential damage.

5 Principle of Operation




Figure 1: Sectional drawing BNA

Figure 2: Detail BNA level indicator

The Bypass Level Indicator (BNA) works according to the principle of operation shown in figure 1.

The tank to be monitored (1/1) is connected with the Bypass Level Indicator (1/4) by two connecting lines (1/3 and 1/3). The liquid to be measured is always at the same level in the tank and in the Bypass Level Indicator.

The float (1/5) contains a magnetic system which acts on the one hand on the magnetic flags of the indication bar (1/7) and on the other hand on the limit switches (1/8) or on the electric transmitter (1/9).

6 Installation/Commissioning

DANGER
<p>The electrical connection may only be made by trained expert staff!</p> <p>Prior to any work on electrical components disconnect them from power supply.</p>

IMPORTANT
<p> When the equipment is used in potentially explosive atmosphere chapter 1 „Intended Applications“ must be observed!</p> <p>If the Bypass Level Indicator (BNA) is determined for use in potentially explosive atmosphere, it must be checked whether the damper has been installed in the bottom flange. The BNA must be suitable for the intended according to its nameplate.</p>

DANGER
<p> In ex areas, only equipment which is in conformity with ATEX may be used. EN 60079-14 must be observed.</p> <p>The BNA-EX must be integrated in the potential equalisation system via the tubing during installation.</p>

IMPORTANT
<p>Before further steps are taken the orderer must check whether the operating conditions agreed in the order are still valid. The equipment must be suitable for the intended purpose. This applies in particular to:</p> <ul style="list-style-type: none"> • the pressure, temperature, medium characteristics • the classification according to the Pressure Equipment Directive • possible additional loads

Mechanical installation

Bypass Level Indicators (BNA) are measuring devices. Perform all work on BNA with utmost care.

- Check whether the Bypass Level Indicator (BNA) supplied is in conformity with your order specification.
- Check whether all parts are available and that the connection flanges of tank and indicator are in conformity.

The float has been packaged and attached to the outside of the Bypass Level Indicator (BNA). Remove the bottom connection flange (1/10) from the BNA.

- Insert the float into the BNA in such a way that the mark (Top) points up.
- Attach the bottom connection flange with its gasket to the BNA.
- Tighten all screws crosswise.

 CAUTION
During erection of the Bypass Level Indicator (BNA) the float may be damaged by bumping. Erect the Bypass Level Indicator (BNA) slowly and carefully.

 DANGER
Depressurize the system before carrying out any work on the Bypass Level Indicator (BNA)!

 IMPORTANT
Ensure that the flanges of the tank are accurately aligned with the flanges of the BNA. Non-alignment of the flanges causes seizing or distortion of the (1/4). The float (1/5) may get jammed. The principle of operation of the Bypass Level Indicator is based on the magnetic field principle. No magnetic iron parts (e.g. screws, clamps etc.) may be used in the vicinity of the level tube.

Observe the data in chapter 8 „Technical Data“.

- Install the BNA so that the nameplate (1/11) of the BNA (1/4) is located at the bottom.
- Align all indication rotors (2/12) by means of a magnet or the enclosed float. All rotors must show the color white or silver;
 - white: makrolon, medium temperature up to 150 °C or aluminium, medium temperature up to 350 °C
 - silver: aluminium, medium temperature up to 200 °C
 - The maximum ambient temperature is 120 °C.
- Ensure that all flange attachment screws, the vent plug (1/13) and the drain screw (1/14) are tightened or closed properly.

Torques for the screws:

Type	Screw dimension	Torque [Nm]
X1	M12	50
Plug	G½, ½" NPT	80
Fastening clamp	7 mm hexagon head	0.75

Electrical installation

 DANGER
The orderer must ensure that all applicable regulations are observed in the event that electric limit switches and remote indicators are used.

For further information about installation of the electric limit switches and remote indicators refer to the corresponding installation and operating instructions.

Commissioning

The Bypass Level Indicators (BNA) are specially made for a specific application. The most important data, such as flange, pressure, temperature and min. specific gravity of the float are precisely specified on the nameplate (1/11).

- Check prior to commissioning whether the technical data according to the nameplate are in agreement with the plant requirements.

Operating pressure and operating temperature of the plant must not exceed the values on the nameplate of the Bypass Level Indicator. Exceeding the limit values will impair the behavior and the service life of the BNA. If the proof pressure is exceeded, functioning of the BNA is no longer guaranteed and the BNA may be damaged.

- Ensure that - dependent on the type of medium to be measured - the appropriate safety precautions are taken.

Filling the Bypass Level Indicator

- Slowly open the top valve (1/2a).
- Slowly open the bottom valve (1/3b).

The liquid rises slowly in the BNA (1/4). The float (1/5) is lifted until the same level is reached in the tank (1/1) and the BNA.

- Fully open the bottom valve (1/3b).

 IMPORTANT
For pressures above 40 bar a vented float (additional designation: -VAE) is used, which is provided with a small pressure compensation tube. When using the VAE version take care take care that the temperature rises evenly and slowly in the BNA and in the float. The use of vented floats should be discussed with the manufacturer beforehand.

7 Maintenance

 DANGER
Depressurize the system before carrying out any work on the Bypass Level Indicator (BNA)!

 DANGER
 Maintenance must not be performed in a potentially explosive atmosphere.

If the liquid to be measured contains dirt particles which may deposit in the bottom part of the BNA:

- Determine the necessary time interval for cleaning.